



## KOLEKCJA ASTOR

### Zestawienie kombinacji





TYP 98 U3 01

S|W|G 2x78/5x79/6x39/12x62/6x60/88/95-00-0A-85  
309 | 245 | 40




TYP 98 U3 02

76/77/2x62/74/3x61/2x38/24/35/09  
314 | 215 | 56





TYP 98 U3 03

04/31/22/74/77/76/2x38/2x62/3x61  
312 | 215 | 56




TYP 98 U3 04

24/33/74/75/2x77/76/2x38/4x62/6x61/85  
313 | 215 | 56





## KOLEKCJA ASTOR



### Zestawienie kombinacji





TYP 98 U3 05  
10/2x62/4x61/2x38/77/11  
205 | 215 | 37



TYP 98 U3 06  
76/38/62/2x61/10/22/35/09  
315 | 215 | 56




TYP 98 U3 08  
2x78/4x79/21/86/2x38/2x80/81/66/67/5x61/6x62  
311 | 245 | 56



TYP 98 U3 L2  
76/77/2x62/74/3x61/2x38/23/35/09  
314 | 215 | 56

KOLEKCJA ASTOR  
Zestawienie kombinacji



---

TYP 98 U3 L4

23/33/74/75/2x77/76/2x38/4x62/6x61/85

313 | 215 | 56